

# Installation Instructions for XLC 4.0 Clamp On Tow Mirror

## Clamp-On Mirror

- Easy On - Easy Off
- Fits Driver or Passenger Side
- Four Point Contact
- Fits Many Types of Vehicles
- Dual Head Design
- No Straps or Ratchets



- Make sure you have correct mirror housing thickness at top and bottom.
- Determine whether mirror will be used on driver or passenger side of vehicle.
- Loosen all four knobs and adjust clamp arms for best fit. Arms open to approximately 13".
- Place mirror on vehicle mirror housing with clamp bracket fitting between vehicle mirror housing and mirror glass.
- Adjust clamp arms to obtain best alignment. Slightly tighten the four bracket knobs.
- Adjust if necessary then continue to tighten all knobs ( you should not be able to pull mirror off vehicle ).
- Wide angle and flat glass mirrors can be adjusted with firm pressure for best viewing position.
- **Do not use this mirror if you cannot securely attach all four clamps to your vehicle mirror.**
- On vehicles with less than 1/4" gap between mirror glass and mirror housing you may not be able to fully adjust vehicle mirror.
- Check frequently to make sure mirror is secure. Tighten knobs if necessary.
- Remove when not towing.



**Check frequently that mirror is securely attached. Consumer must determine suitability of this mirror to their particular vehicle. Do not use this mirror if you cannot securely attach it to your tow vehicle. While this mirror will fit many vehicles it will not fit all.**



XLC 4.0 fits many popular tow vehicles. Vehicle mirror housing must not be thicker than 3/8" at the top and bottom. There should be at least 1/4" gap between glass and housing to allow vehicle mirror to adjust. See below.



XLC 4.0 Mirror will not fit some late model trucks or any mirror with a housing thickness that is irregular or thicker than 3/8", top or bottom.

**Please contact us at 800-327-7463 or 562-531-1395 for additional information.**